

# STM32 CubeMX

## 1. Description

### 1.1. Project

Project Name	BHBF_Robot_Detect
Board Name	custom
Generated with:	STM32CubeMX 6.11.0
Date	06/25/2024


### 1.2. MCU

MCU Series	STM32H7
MCU Line	STM32H743/753
MCU name	STM32H743VGTx
MCU Package	LQFP100
MCU Pin number	100

### 1.3. Core(s) information

Core(s)	ARM Cortex-M7
---------	---------------

## 2. Pinout Configuration



### 3. Pins Configuration


Pin Number LQFP100	Pin Name (function after reset)	Pin Type	Alternate Function(s)	Label
1	PE2 *	I/O	GPIO_Input	IN_0
2	PE3 *	I/O	GPIO_Input	IN_1
3	PE4 *	I/O	GPIO_Input	IN_2
4	PE5 *	I/O	GPIO_Input	IN_3
5	PE6 *	I/O	GPIO_Input	IN_4
6	VBAT	Power		
7	PC13 *	I/O	GPIO_Input	IN_5
10	VSS	Power		
11	VDD	Power		
12	PH0-OSC_IN (PH0)	I/O	RCC_OSC_IN	
13	PH1-OSC_OUT (PH1)	I/O	RCC_OSC_OUT	
14	NRST	Reset		
15	PC0 *	I/O	GPIO_Output	RST_WDI
16	PC1	I/O	ETH_MDC	
17	PC2_C *	I/O	GPIO_Output	OUT_0
18	PC3_C *	I/O	GPIO_Output	OUT_1
19	VSSA	Power		
21	VDDA	Power		
22	PA0 *	I/O	GPIO_Output	OUT_2
23	PA1	I/O	ETH_REF_CLK	
24	PA2	I/O	ETH_MDIO	
25	PA3 *	I/O	GPIO_Output	OUT_3
26	VSS	Power		
27	VDD	Power		
28	PA4 *	I/O	GPIO_Output	OUT_4
29	PA5 *	I/O	GPIO_Output	OUT_5
30	PA6 *	I/O	GPIO_Output	ETH_RST
31	PA7	I/O	ETH_CRSDV	
32	PC4	I/O	ETH_RXD0	
33	PC5	I/O	ETH_RXD1	
41	PE11 *	I/O	GPIO_Output	EEPROM_WP
42	PE12 *	I/O	GPIO_Output	EEPROM_SCL
43	PE13 *	I/O	GPIO_Input	EEPROM_SDA
47	PB11	I/O	ETH_TX_EN	
48	VCAP	Power		
49	VSS	Power		

Pin Number LQFP100	Pin Name (function after reset)	Pin Type	Alternate Function(s)	Label
50	VDD	Power		
51	PB12	I/O	ETH_TXD0	
52	PB13	I/O	ETH_TXD1	
53	PB14	I/O	USART1_TX	
54	PB15	I/O	USART1_RX	
55	PD8	I/O	USART3_TX	
56	PD9	I/O	USART3_RX	
57	PD10 *	I/O	GPIO_Output	RS485_1_DIR
58	PD11 *	I/O	GPIO_Output	RS485_2_DIR
59	PD12	I/O	I2C4_SCL	
60	PD13	I/O	I2C4_SDA	
61	PD14	I/O	GPIO_EXTI14	
63	PC6	I/O	USART6_TX	
64	PC7	I/O	USART6_RX	
65	PC8 *	I/O	GPIO_Output	RS485_3_DIR
66	PC9 *	I/O	GPIO_Output	RS485_4_DIR
67	PA8	I/O	UART7_RX	
70	PA11	I/O	UART4_RX	
71	PA12	I/O	UART4_TX	
72	PA13 (JTMS/SWDIO)	I/O	DEBUG_JTMS-SWDIO	
73	VCAP	Power		
74	VSS	Power		
75	VDD	Power		
76	PA14 (JTCK/SWCLK)	I/O	DEBUG_JTCK-SWCLK	
77	PA15 (JTDI)	I/O	UART7_TX	
78	PC10 *	I/O	GPIO_Output	E22_RST
80	PC12	I/O	UART5_TX	
81	PD0 *	I/O	GPIO_Output	E28_M0
82	PD1 *	I/O	GPIO_Output	E28_M1
83	PD2	I/O	UART5_RX	
84	PD3 *	I/O	GPIO_Output	E28_M2
85	PD4	I/O	GPIO_EXTI4	E28_AUX
86	PD5	I/O	USART2_TX	
87	PD6	I/O	USART2_RX	
91	PB5	I/O	FDCAN2_RX	
92	PB6	I/O	FDCAN2_TX	
93	PB7 *	I/O	GPIO_Output	E22_M1
94	BOOT0	Boot		
95	PB8	I/O	FDCAN1_RX	

Pin Number LQFP100	Pin Name (function after reset)	Pin Type	Alternate Function(s)	Label
96	PB9	I/O	FDCAN1_TX	
97	PE0 *	I/O	GPIO_Output	E22_M0
98	PE1	I/O	GPIO_EXTI1	E22_AUX
99	VSS	Power		
100	VDD	Power		

\* The pin is affected with an I/O function

## 4. Clock Tree Configuration



## 5. Software Project

### 5.1. Project Settings

Name	Value
Project Name	BHBF_Robot_Detect
Project Folder	D:\WeChat Files\WeChat Files\wxid_mnyr7127xheu22\FileStorage\File\2024-
Toolchain / IDE	STM32CubeIDE
Firmware Package Name and Version	STM32Cube FW_H7 V1.10.0
Application Structure	Advanced
Generate Under Root	Yes
Do not generate the main()	No
Minimum Heap Size	0x400
Minimum Stack Size	0x1000

### 5.2. Code Generation Settings

Name	Value
STM32Cube MCU packages and embedded software	Copy only the necessary library files
Generate peripheral initialization as a pair of '.c/.h' files	Yes
Backup previously generated files when re-generating	No
Keep User Code when re-generating	Yes
Delete previously generated files when not re-generated	Yes
Set all free pins as analog (to optimize the power consumption)	No
Enable Full Assert	No

### 5.3. Advanced Settings - Generated Function Calls

Rank	Function Name	Peripheral Instance Name
1	SystemClock_Config	RCC
2	MX_GPIO_Init	GPIO
3	MX_DMA_Init	DMA
4	MX_FDCAN1_Init	FDCAN1
5	MX_FDCAN2_Init	FDCAN2
6	MX_I2C4_Init	I2C4
7	MX_TIM1_Init	TIM1
8	MX_UART4_Init	UART4
9	MX_UART5_Init	UART5
10	MX_UART7_Init	UART7
11	MX_USART1_UART_Init	USART1



Rank	Function Name	Peripheral Instance Name
12	MX_USART3_UART_Init	USART3
13	MX_USART2_UART_Init	USART2
14	MX_USART6_UART_Init	USART6
15	MX_TIM8_Init	TIM8
16	MX_LWIP_Init	LWIP

## 1. Power Consumption Calculator report

### 1.1. Microcontroller Selection

Series	STM32H7
Line	STM32H743/753
MCU	STM32H743VGTx
Datasheet	DS12110_Rev8

### 1.2. Parameter Selection

Temperature	25
Vdd	3.0

### 1.3. Battery Selection

Battery	Alkaline(9V)
Capacity	625.0 mAh
Self Discharge	0.3 %/month
Nominal Voltage	9.0 V
Max Cont Current	200.0 mA
Max Pulse Current	0.0 mA
Cells in series	1
Cells in parallel	1


#### 1.4. Sequence

<b>Step</b>	Step1	Step2
<b>Mode</b>	RUN	STOP
<b>Vdd</b>	3.0	3.0
<b>Voltage Source</b>	Battery	Battery
<b>Range</b>	VOS0: Scale0-High	SVOS5: System-Scale5
<b>D1 Mode</b>	DRUN/CRUN	DSTANDBY
<b>D2 Mode</b>	DRUN	DSTANDBY
<b>D3 Mode</b>	DRUN	DSTOP
<b>Fetch Type</b>	ITCM	NA
<b>CPU Frequency</b>	480 MHz	0 Hz
<b>Clock Configuration</b>	HSE BYP PLL	Flash-OFF
<b>Clock Source Frequency</b>	24 MHz	0 Hz
<b>Peripherals</b>		
<b>Additional Cons.</b>	0 mA	0 mA
<b>Average Current</b>	148 mA	150 $\mu$ A
<b>Duration</b>	0.1 ms	0.9 ms
<b>DMIPS</b>	1027.0	0.0
<b>Ta Max</b>	105.02	124.98
<b>Category</b>	In DS Table	In DS Table

#### 1.5. Results

Sequence Time	1 ms	Average Current	14.94 mA
Battery Life	1 day, 17 hours	Average DMIPS	1027.2001 DMIPS

#### 1.6. Chart



## 2. Peripherals and Middlewares Configuration

### 2.1. CORTEX\_M7

#### 2.1.1. Parameter Settings:

##### Speculation default mode Settings:

Speculation default mode Disabled

##### Cortex Interface Settings:

CPU ICache Enabled \*

CPU DCache Enabled \*

##### Cortex Memory Protection Unit Control Settings:

MPU Control Mode Background Region Privileged accesses only + MPU Disabled during hard fault, NMI and FAULTMASK handlers \*

##### Cortex Memory Protection Unit Region 0 Settings:

MPU Region Enabled \*

MPU Region Base Address 0x30040000 \*

MPU Region Size 32KB \*

MPU SubRegion Disable 0x0 \*

MPU TEX field level level 1 \*

MPU Access Permission ALL ACCESS PERMITTED \*

MPU Instruction Access DISABLE \*

MPU Shareability Permission DISABLE

MPU Cacheable Permission DISABLE

MPU Bufferable Permission DISABLE

##### Cortex Memory Protection Unit Region 1 Settings:

MPU Region Enabled \*

MPU Region Base Address 0x30040000 \*

MPU Region Size 1KB \*

MPU SubRegion Disable 0x0 \*

MPU TEX field level level 0

MPU Access Permission ALL ACCESS PERMITTED \*

MPU Instruction Access DISABLE \*

MPU Shareability Permission ENABLE \*

MPU Cacheable Permission DISABLE

MPU Bufferable Permission ENABLE \*

##### Cortex Memory Protection Unit Region 2 Settings:

MPU Region Enabled \*

MPU Region Base Address

	<b>0x30030000 *</b>
MPU Region Size	<b>32KB *</b>
MPU SubRegion Disable	<b>0x0 *</b>
MPU TEX field level	<b>level 1 *</b>
MPU Access Permission	<b>ALL ACCESS PERMITTED *</b>
MPU Instruction Access	<b>DISABLE *</b>
MPU Shareability Permission	DISABLE
MPU Cacheable Permission	DISABLE
MPU Bufferable Permission	DISABLE

**Cortex Memory Protection Unit Region 3 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 4 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 5 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 6 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 7 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 8 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 9 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 10 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 11 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 12 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 13 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 14 Settings:**

MPU Region Disabled

**Cortex Memory Protection Unit Region 15 Settings:**

MPU Region Disabled

## 2.2. DEBUG

### Debug: Serial Wire

## 2.3. ETH

### Mode: RMII

#### 2.3.1. Parameter Settings:

##### General : Ethernet Configuration:

Warning	The ETH can work only when RAM is pointing at 0x24000000
Note	PHY Driver must be configured from the LwIP 'Platform Settings' top right tab
Ethernet MAC Address	00:80:E1:00:00:00
Tx Descriptor Length	4
First Tx Descriptor Address	<b>0x30040200 *</b>
Rx Descriptor Length	4
First Rx Descriptor Address	<b>0x30040000 *</b>
Rx Buffers Address	<b>0x30040400 *</b>
Rx Buffers Length	<b>1528 *</b>

## 2.4. FDCAN1

### mode: Activated

#### 2.4.1. Parameter Settings:

##### Basic Parameters:

Frame Format	Classic mode
Mode	Normal mode
Auto Retransmission	Disable
Transmit Pause	Disable
Protocol Exception	Disable
Nominal Prescaler	<b>10 *</b>
Nominal Sync Jump Width	1
Nominal Time Seg1	<b>5 *</b>
Nominal Time Seg2	2
Data Prescaler	1
Data Sync Jump Width	1
Data Time Seg1	1
Data Time Seg2	1
Message Ram Offset	0
Std Filters Nbr	0

Ext Filters Nbr	0
Rx Fifo0 Elmts Nbr	<b>32 *</b>
Rx Fifo0 Elmt Size	8 bytes data field
Rx Fifo1 Elmts Nbr	0
Rx Fifo1 Elmt Size	8 bytes data field
Rx Buffers Nbr	0
Rx Buffer Size	8 bytes data field
Tx Events Nbr	0
Tx Buffers Nbr	0
Tx Fifo Queue Elmts Nbr	<b>32 *</b>
Tx Fifo Queue Mode	FIFO mode
Tx Elmt Size	8 bytes data field

**Clock Calibration Unit:**

Clock Calibration	Disable
-------------------	---------

## 2.5. FDCAN2

**mode: Activated**

### 2.5.1. Parameter Settings:

**Basic Parameters:**

Frame Format	Classic mode
Mode	Normal mode
Auto Retransmission	Disable
Transmit Pause	Disable
Protocol Exception	Disable
Nominal Prescaler	<b>10 *</b>
Nominal Sync Jump Width	1
Nominal Time Seg1	<b>5 *</b>
Nominal Time Seg2	2
Data Prescaler	1
Data Sync Jump Width	1
Data Time Seg1	1
Data Time Seg2	1
Message Ram Offset	0
Std Filters Nbr	0
Ext Filters Nbr	0
Rx Fifo0 Elmts Nbr	<b>32 *</b>
Rx Fifo0 Elmt Size	8 bytes data field
Rx Fifo1 Elmts Nbr	0



Rx Fifo1 Elmt Size	8 bytes data field
Rx Buffers Nbr	0
Rx Buffer Size	8 bytes data field
Tx Events Nbr	0
Tx Buffers Nbr	0
Tx Fifo Queue Elmts Nbr	<b>32 *</b>
Tx Fifo Queue Mode	FIFO mode
Tx Elmt Size	8 bytes data field
<b>Clock Calibration Unit:</b>	
Clock Calibration	Disable

## 2.6. I2C4

### I2C: I2C

#### 2.6.1. Parameter Settings:

##### **Timing configuration:**

Custom Timing	Disabled
I2C Speed Mode	Standard Mode
I2C Speed Frequency (KHz)	100
Rise Time (ns)	0
Fall Time (ns)	0
Coefficient of Digital Filter	0
Analog Filter	Enabled
Timing	<b>0x10C0ECFF *</b>

##### **Slave Features:**

Clock No Stretch Mode	Disabled
General Call Address Detection	Disabled
Primary Address Length selection	7-bit
Dual Address Acknowledged	Disabled
Primary slave address	0

## 2.7. RCC

### **High Speed Clock (HSE): Crystal/Ceramic Resonator**

#### 2.7.1. Parameter Settings:

##### **Power Parameters:**

SupplySource	PWR_LDO_SUPPLY
--------------	----------------

Power Regulator Voltage Scale                      Power Regulator Voltage Scale 1

**RCC Parameters:**

TIM Prescaler Selection	Disabled
HSE Startup Timeout Value (ms)	100
LSE Startup Timeout Value (ms)	5000
CSI Calibration Value	16
HSI Calibration Value	32

**System Parameters:**

VDD voltage (V)	3.3
Flash Latency(WS)	2 WS (3 CPU cycle)
Product revision	rev.Y

**PLL range Parameters:**

PLL1 clock Input range	Between 8 and 16 MHz
PLL1 clock Output range	Wide VCO range

## 2.8. SYS

**Timebase Source: SysTick**

## 2.9. TIM1

**Clock Source : Internal Clock**

### 2.9.1. Parameter Settings:

**Counter Settings:**

Prescaler (PSC - 16 bits value)	<b>2000-1 *</b>
Counter Mode	Up
Counter Period (AutoReload Register - 16 bits value )	<b>10000-1 *</b>
Internal Clock Division (CKD)	No Division
Repetition Counter (RCR - 16 bits value)	0
auto-reload preload	<b>Enable *</b>

**Trigger Output (TRGO) Parameters:**

Master/Slave Mode (MSM bit)	Disable (Trigger input effect not delayed)
Trigger Event Selection TRGO	Reset (UG bit from TIMx_EGR)
Trigger Event Selection TRGO2	Reset (UG bit from TIMx_EGR)

## 2.10. TIM8

**Clock Source : Internal Clock**

### 2.10.1. Parameter Settings:

#### **Counter Settings:**

Prescaler (PSC - 16 bits value)	<b>20000-1 *</b>
Counter Mode	Up
Counter Period (AutoReload Register - 16 bits value )	<b>200-1 *</b>
Internal Clock Division (CKD)	No Division
Repetition Counter (RCR - 16 bits value)	0
auto-reload preload	Disable

#### **Trigger Output (TRGO) Parameters:**

Master/Slave Mode (MSM bit)	Disable (Trigger input effect not delayed)
Trigger Event Selection TRGO	Reset (UG bit from TIMx_EGR)
Trigger Event Selection TRGO2	Reset (UG bit from TIMx_EGR)

## **2.11. UART4**

### **Mode: Asynchronous**

### 2.11.1. Parameter Settings:

#### **Basic Parameters:**

Baud Rate	115200
Word Length	8 Bits (including Parity)
Parity	None
Stop Bits	1

#### **Advanced Parameters:**

Data Direction	Receive and Transmit
Over Sampling	16 Samples
Single Sample	Disable
ClockPrescaler	1
Fifo Mode	FIFO mode disable
Txfifo Threshold	1 eighth full configuration
Rxfifo Threshold	1 eighth full configuration

#### **Advanced Features:**

Auto Baudrate	Disable
TX Pin Active Level Inversion	Disable
RX Pin Active Level Inversion	Disable
Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	Enable
DMA on RX Error	Enable

MSB First Disable

## 2.12. UART5

### Mode: Asynchronous

#### 2.12.1. Parameter Settings:

##### Basic Parameters:

Baud Rate	<b>100000 *</b>
Word Length	<b>9 Bits (including Parity) *</b>
Parity	<b>Even *</b>
Stop Bits	1

##### Advanced Parameters:

Data Direction	Receive and Transmit
Over Sampling	16 Samples
Single Sample	Disable
ClockPrescaler	1
Fifo Mode	FIFO mode disable
Txfifo Threshold	1 eighth full configuration
Rxfifo Threshold	1 eighth full configuration

##### Advanced Features:

Auto Baudrate	Disable
TX Pin Active Level Inversion	Disable
RX Pin Active Level Inversion	Disable
Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	<b>Disable *</b>
DMA on RX Error	Enable
MSB First	Disable

## 2.13. UART7

### Mode: Asynchronous

#### 2.13.1. Parameter Settings:

##### Basic Parameters:

Baud Rate	115200
Word Length	8 Bits (including Parity)
Parity	None

Stop Bits 1

**Advanced Parameters:**

Data Direction Receive and Transmit  
Over Sampling 16 Samples  
Single Sample Disable  
ClockPrescaler 1  
Fifo Mode FIFO mode disable  
Txfifo Threshold 1 eighth full configuration  
Rxfifo Threshold 1 eighth full configuration

**Advanced Features:**

Auto Baudrate Disable  
TX Pin Active Level Inversion Disable  
RX Pin Active Level Inversion Disable  
Data Inversion Disable  
TX and RX Pins Swapping Disable  
Overrun Enable  
DMA on RX Error Enable  
MSB First Disable

## 2.14. USART1

### Mode: Asynchronous

#### 2.14.1. Parameter Settings:

**Basic Parameters:**

Baud Rate 115200  
Word Length 8 Bits (including Parity)  
Parity None  
Stop Bits 1

**Advanced Parameters:**

Data Direction Receive and Transmit  
Over Sampling 16 Samples  
Single Sample Disable  
ClockPrescaler 1  
Fifo Mode Disable  
Txfifo Threshold 1 eighth full configuration  
Rxfifo Threshold 1 eighth full configuration

**Advanced Features:**

Auto Baudrate Disable  
TX Pin Active Level Inversion Disable  
RX Pin Active Level Inversion Disable

Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	Enable
DMA on RX Error	Enable
MSB First	Disable

## 2.15. USART2

### Mode: Asynchronous

#### 2.15.1. Parameter Settings:

##### Basic Parameters:

Baud Rate	115200
Word Length	8 Bits (including Parity)
Parity	None
Stop Bits	1

##### Advanced Parameters:

Data Direction	Receive and Transmit
Over Sampling	16 Samples
Single Sample	Disable
ClockPrescaler	1
Fifo Mode	Disable
Txfifo Threshold	1 eighth full configuration
Rxfifo Threshold	1 eighth full configuration

##### Advanced Features:

Auto Baudrate	Disable
TX Pin Active Level Inversion	Disable
RX Pin Active Level Inversion	Disable
Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	Enable
DMA on RX Error	Enable
MSB First	Disable

## 2.16. USART3

### Mode: Asynchronous

#### 2.16.1. Parameter Settings:

##### Basic Parameters:

Baud Rate	115200
Word Length	8 Bits (including Parity)
Parity	None
Stop Bits	1

**Advanced Parameters:**

Data Direction	Receive and Transmit
Over Sampling	16 Samples
Single Sample	Disable
ClockPrescaler	1
Fifo Mode	Disable
Txfifo Threshold	1 eighth full configuration
Rxfifo Threshold	1 eighth full configuration

**Advanced Features:**

Auto Baudrate	Disable
TX Pin Active Level Inversion	Disable
RX Pin Active Level Inversion	Disable
Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	Enable
DMA on RX Error	Enable
MSB First	Disable

## 2.17. USART6

### Mode: Asynchronous

#### 2.17.1. Parameter Settings:

**Basic Parameters:**

Baud Rate	115200
Word Length	8 Bits (including Parity)
Parity	None
Stop Bits	1

**Advanced Parameters:**

Data Direction	Receive and Transmit
Over Sampling	16 Samples
Single Sample	Disable
ClockPrescaler	1
Fifo Mode	Disable
Txfifo Threshold	1 eighth full configuration
Rxfifo Threshold	1 eighth full configuration

**Advanced Features:**

Auto Baudrate	Disable
TX Pin Active Level Inversion	Disable
RX Pin Active Level Inversion	Disable
Data Inversion	Disable
TX and RX Pins Swapping	Disable
Overrun	Enable
DMA on RX Error	Enable
MSB First	Disable

## 2.18. LWIP

**mode: Enabled**

Advanced parameters are not listed except if modified by user.

### 2.18.1. General Settings:

#### **LwIP Version:**

LwIP Version (Version of LwIP supported by CubeMX \*\* CubeMX specific \*\*) 2.1.2

#### **IPv4 - DHCP Options:**

LWIP\_DHCP (DHCP Module) **Disabled \***

#### **IP Address Settings:**

IP\_ADDRESS (IP Address) **192.168.024.010 \***

NETMASK\_ADDRESS (Netmask Address) **255.255.255.000 \***

GATEWAY\_ADDRESS (Gateway Address) **192.168.024.001 \***

#### **RTOS Dependency:**

WITH\_RTOS (Use FREERTOS \*\* CubeMX specific \*\*) Disabled

#### **Platform Settings:**

PHY Driver Choose/LAN8742

#### **Protocols Options:**

LWIP\_ICMP (ICMP Module Activation) Enabled

LWIP\_IGMP (IGMP Module) Disabled

LWIP\_DNS (DNS Module) Disabled

LWIP\_UDP (UDP Module) Enabled

MEMP\_NUM\_UDP\_PCB (Number of UDP Connections) 4

LWIP\_TCP (TCP Module) Enabled

MEMP\_NUM\_TCP\_PCB (Number of TCP Connections) 5

### 2.18.2. Key Options:

#### **Infrastructure - OS Awareness Option:**



NO\_SYS (OS Awareness) OS Not Used

**Infrastructure - Timers Options:**

LWIP\_TIMERS (Use Support For sys\_timeout) Enabled

**Infrastructure - Core Locking and MPU Options:**

SYS\_LIGHTWEIGHT\_PROT (Memory Functions Protection) Disabled

**Infrastructure - Heap and Memory Pools Options:**

MEM\_SIZE (Heap Memory Size) 1600

LWIP\_RAM\_HEAP\_POINTER (RAM Heap Pointer) **0x30044000 \***

**Infrastructure - Internal Memory Pool Sizes:**

MEMP\_NUM\_PBUF (Number of Memory Pool struct Pbufs) 16

MEMP\_NUM\_RAW\_PCB (Number of Raw Protocol Control Blocks) 4

MEMP\_NUM\_TCP\_PCB\_LISTEN (Number of Listening TCP Connections) 8

MEMP\_NUM\_TCP\_SEG (Number of TCP Segments simultaneously queued) 16

MEMP\_NUM\_LOCALHOSTLIST (Number of Host Entries in the Local Host List) 1

**Pbuf Options:**

PBUF\_POOL\_SIZE (Number of Buffers in the Pbuf Pool) 16

PBUF\_POOL\_BUFSIZE (Size of each pbuf in the pbuf pool) 592

**IPv4 - ARP Options:**

LWIP\_ARP (ARP Functionality) Enabled

**Callback - TCP Options:**

TCP\_TTL (Number of Time-To-Live Used by TCP Packets) 255

TCP\_WND (TCP Receive Window Maximum Size) 2144

TCP\_QUEUE\_OOSEQ (Allow Out-Of-Order Incoming Packets) Enabled

LWIP\_TCP\_SACK\_OUT (Allow Sending Selective Acknowledgements) Disabled

TCP\_MSS (Maximum Segment Size) 536

TCP\_SND\_BUF (TCP Sender Buffer Space) 1072

TCP\_SND\_QUEUELEN (Number of Packet Buffers Allowed for TCP Sender) 9

**Network Interfaces Options:**

LWIP\_NETIF\_STATUS\_CALLBACK (Callback Function on Interface Status Changes) **Enabled \***

LWIP\_NETIF\_EXT\_STATUS\_CALLBACK (Extended Callback Function for several netif) Disabled

LWIP\_NETIF\_LINK\_CALLBACK (Callback Function on Interface Link Changes) Enabled

**NETIF - Loopback Interface Options:**

LWIP\_NETIF\_LOOPBACK (NETIF Loopback) Disabled

**Thread Safe APIs - Socket Options:**

LWIP\_SOCKET (Socket API) Disabled

2.18.3. PPP:

**PPP Options:**

PPP\_SUPPORT (PPP Module) Disabled

#### 2.18.4. IPv6:

##### **IPv6 Options:**

LWIP\_IPV6 (IPv6 Protocol) Disabled

#### 2.18.5. HTTPD:

##### **HTTPD Options:**

LWIP\_HTTPD (LwIP HTTPD Support \*\* CubeMX specific \*\*) Disabled

#### 2.18.6. SNMP:

##### **SNMP Options:**

LWIP\_SNMP (LwIP SNMP Agent) Disabled

#### 2.18.7. SNTP/SMTP:

##### **SNTP Options:**

LWIP\_SNTP (LWIP SNTP Support \*\* CubeMX specific \*\*) Disabled

##### **SMTP Options:**

LWIP\_SMTP (LWIP SMTP Support \*\* CubeMX specific \*\*) Disabled

#### 2.18.8. MDNS/TFTP:

##### **MDNS Options:**

LWIP\_MDNS (Multicast DNS Support \*\* CubeMX specific \*\*) Disabled

##### **TFTP Options:**

LWIP\_TFTP (TFTP Support \*\* CubeMX specific \*\*) Disabled

#### 2.18.9. Perf/Checks:

##### **Sanity Checks:**

LWIP\_DISABLE\_TCP\_SANITY\_CHECKS (TCP Sanity Checks) Disabled

LWIP\_DISABLE\_MEMP\_SANITY\_CHECKS (MEMP Sanity Checks) Disabled

##### **Performance Options:**

LWIP\_PERF (Performance Testing for LwIP) Disabled

### 2.18.10. Statistics:

#### **Debug - Statistics Options:**

LWIP\_STATS (Statistics Collection) Disabled

### 2.18.11. Checksum:

#### **Infrastructure - Checksum Options:**

CHECKSUM_BY_HARDWARE (Hardware Checksum ** CubeMX specific **)	Enabled
LWIP_CHECKSUM_CTRL_PER_NETIF (Generate/Check Checksum per Netif)	Disabled
CHECKSUM_GEN_IP (Generate Software Checksum for Outgoing IP Packets)	Disabled
CHECKSUM_GEN_UDP (Generate Software Checksum for Outgoing UDP Packets)	Disabled
CHECKSUM_GEN_TCP (Generate Software Checksum for Outgoing TCP Packets)	Disabled
CHECKSUM_GEN_ICMP (Generate Software Checksum for Outgoing ICMP Packets)	Enabled
CHECKSUM_GEN_ICMP6 (Generate Software Checksum for Outgoing ICMP6 Packets)	Disabled
CHECKSUM_CHECK_IP (Generate Software Checksum for Incoming IP Packets)	Disabled
CHECKSUM_CHECK_UDP (Generate Software Checksum for Incoming UDP Packets)	Disabled
CHECKSUM_CHECK_TCP (Generate Software Checksum for Incoming TCP Packets)	Disabled
CHECKSUM_CHECK_ICMP (Generate Software Checksum for Incoming ICMP Packets)	Enabled
CHECKSUM_CHECK_ICMP6 (Generate Software Checksum for Incoming ICMP6 Packets)	Disabled

### 2.18.12. Debug:

#### **LwIP Main Debugging Options:**

LWIP\_DBG\_MIN\_LEVEL (Minimum Level) All

### 2.18.13. Platform Settings:

Driver\_PHY LAN8742

\* User modified value

### 3. System Configuration

#### 3.1. GPIO configuration

IP	Pin	Signal	GPIO mode	GPIO pull/up pull down	Max Speed	User Label
DEBUG	PA13 (JTMS/SWDIO)	DEBUG_JTMS-SWDIO	n/a	n/a	n/a	
	PA14 (JTCK/SWCLK)	DEBUG_JTCK-SWCLK	n/a	n/a	n/a	
ETH	PC1	ETH_MDC	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PA1	ETH_REF_CLK	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PA2	ETH_MDIO	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PA7	ETH_CRS_DV	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PC4	ETH_RXD0	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PC5	ETH_RXD1	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PB11	ETH_TX_EN	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PB12	ETH_TXD0	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
	PB13	ETH_TXD1	Alternate Function Push Pull	No pull-up and no pull-down	Very High *	
FDCAN1	PB8	FDCAN1_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PB9	FDCAN1_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
FDCAN2	PB5	FDCAN2_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PB6	FDCAN2_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
I2C4	PD12	I2C4_SCL	Alternate Function Open Drain	No pull-up and no pull-down	Low	
	PD13	I2C4_SDA	Alternate Function Open Drain	No pull-up and no pull-down	Low	
RCC	PH0-OSC_IN (PH0)	RCC_OSC_IN	n/a	n/a	n/a	
	PH1-	RCC_OSC_OUT	n/a	n/a	n/a	

BHBF\_Robot\_Detect Project  
Configuration Report

IP	Pin	Signal	GPIO mode	GPIO pull/up pull down	Max Speed	User Label
	OSC_OUT (PH1)					
UART4	PA11	UART4_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PA12	UART4_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
UART5	PC12	UART5_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PD2	UART5_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
UART7	PA8	UART7_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PA15 (JTDI)	UART7_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
USART1	PB14	USART1_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PB15	USART1_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
USART2	PD5	USART2_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PD6	USART2_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
USART3	PD8	USART3_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PD9	USART3_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
USART6	PC6	USART6_TX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
	PC7	USART6_RX	Alternate Function Push Pull	No pull-up and no pull-down	Low	
GPIO	PE2	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_0
	PE3	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_1
	PE4	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_2
	PE5	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_3
	PE6	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_4
	PC13	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	IN_5
	PC0	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	RST_WDI
	PC2_C	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_0
	PC3_C	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_1
	PA0	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_2
	PA3	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_3
	PA4	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_4
	PA5	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	OUT_5
	PA6	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	ETH_RST
	PE11	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	EEPROM_WP
	PE12	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	EEPROM_SCL
	PE13	GPIO_Input	Input mode	No pull-up and no pull-down	n/a	EEPROM_SDA
	PD10	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	RS485_1_DIR
	PD11	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	RS485_2_DIR
	PD14	GPIO_EXTI14	External Interrupt Mode with Rising edge trigger detection	No pull-up and no pull-down	n/a	
	PC8	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	RS485_3_DIR
	PC9	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	RS485_4_DIR
	PC10	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E22_RST
PD0	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E28_M0	

IP	Pin	Signal	GPIO mode	GPIO pull/up pull down	Max Speed	User Label
	PD1	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E28_M1
	PD3	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E28_M2
	PD4	GPIO_EXTI4	External Interrupt Mode with Rising edge trigger detection	No pull-up and no pull-down	n/a	E28_AUX
	PB7	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E22_M1
	PE0	GPIO_Output	Output Push Pull	No pull-up and no pull-down	Low	E22_M0
	PE1	GPIO_EXTI1	External Interrupt Mode with Rising edge trigger detection	No pull-up and no pull-down	n/a	E22_AUX

### 3.2. DMA configuration

DMA request	Stream	Direction	Priority
UART4_TX	DMA1_Stream0	Memory To Peripheral	Low
UART4_RX	DMA1_Stream1	Peripheral To Memory	Low
USART1_TX	DMA1_Stream2	Memory To Peripheral	Low

#### UART4\_TX: DMA1\_Stream0 DMA request Settings:

Mode: Normal  
 Use fifo: **Enable \***  
 FIFO Threshold: Full  
 Peripheral Increment: Disable  
 Memory Increment: **Enable \***  
 Peripheral Data Width: Byte  
 Memory Data Width: Byte  
 Peripheral Burst Size: Single  
 Memory Burst Size: Single

#### UART4\_RX: DMA1\_Stream1 DMA request Settings:

Mode: Normal  
 Use fifo: **Enable \***  
 FIFO Threshold: Full  
 Peripheral Increment: Disable  
 Memory Increment: **Enable \***  
 Peripheral Data Width: Byte  
 Memory Data Width: Byte  
 Peripheral Burst Size: Single  
 Memory Burst Size: Single

#### USART1\_TX: DMA1\_Stream2 DMA request Settings:

Mode: Normal  
 Use fifo: **Enable \***  
 FIFO Threshold: Full  
 Peripheral Increment: Disable  
 Memory Increment: **Enable \***  
 Peripheral Data Width: Byte

Memory Data Width: Byte  
Peripheral Burst Size: Single  
Memory Burst Size: Single

### **3.3. BDMA configuration**

nothing configured in DMA service

### **3.4. MDMA configuration**

nothing configured in DMA service



### 3.5. NVIC configuration

#### 3.5.1. NVIC

Interrupt Table	Enable	Preenmption Priority	SubPriority
Non maskable interrupt	true	0	0
Hard fault interrupt	true	0	0
Memory management fault	true	0	0
Pre-fetch fault, memory access fault	true	0	0
Undefined instruction or illegal state	true	0	0
System service call via SWI instruction	true	0	0
Debug monitor	true	0	0
Pendable request for system service	true	0	0
System tick timer	true	15	0
DMA1 stream0 global interrupt	true	0	0
DMA1 stream1 global interrupt	true	0	0
DMA1 stream2 global interrupt	true	0	0
FDCAN1 interrupt 0	true	0	0
FDCAN2 interrupt 0	true	0	0
TIM1 update interrupt	true	0	0
USART1 global interrupt	true	0	0
TIM8 update interrupt and TIM13 global interrupt	true	0	0
UART4 global interrupt	true	0	0
UART5 global interrupt	true	0	0
Ethernet global interrupt	true	6	0
I2C4 event interrupt	true	0	0
I2C4 error interrupt	true	0	0
PVD and AVD interrupts through EXTI line 16		unused	
Flash global interrupt		unused	
RCC global interrupt		unused	
EXTI line1 interrupt		unused	
EXTI line4 interrupt		unused	
FDCAN1 interrupt 1		unused	
FDCAN2 interrupt 1		unused	
TIM1 break interrupt		unused	
TIM1 trigger and commutation interrupts		unused	
TIM1 capture compare interrupt		unused	
USART2 global interrupt		unused	
USART3 global interrupt		unused	
EXTI line[15:10] interrupts		unused	
TIM8 break interrupt and TIM12 global interrupt		unused	
TIM8 trigger and commutation interrupts and		unused	

Interrupt Table	Enable	Preenmption Priority	SubPriority
TIM14 global interrupt			
TIM8 capture compare interrupt		unused	
Ethernet wake-up interrupt through EXTI line 86		unused	
FDCAN calibration unit interrupt		unused	
USART6 global interrupt		unused	
FPU global interrupt		unused	
UART7 global interrupt		unused	
HSEM1 global interrupt		unused	

### 3.5.2. NVIC Code generation

Enabled interrupt Table	Select for init sequence ordering	Generate IRQ handler	Call HAL handler
Non maskable interrupt	false	true	false
Hard fault interrupt	false	true	false
Memory management fault	false	true	false
Pre-fetch fault, memory access fault	false	true	false
Undefined instruction or illegal state	false	true	false
System service call via SWI instruction	false	true	false
Debug monitor	false	true	false
Pendable request for system service	false	true	false
System tick timer	false	true	true
DMA1 stream0 global interrupt	false	true	true
DMA1 stream1 global interrupt	false	true	true
DMA1 stream2 global interrupt	false	true	true
FDCAN1 interrupt 0	false	true	true
FDCAN2 interrupt 0	false	true	true
TIM1 update interrupt	false	true	true
USART1 global interrupt	false	true	true
TIM8 update interrupt and TIM13 global interrupt	false	true	true
UART4 global interrupt	false	true	true
UART5 global interrupt	false	true	true
Ethernet global interrupt	false	true	true
I2C4 event interrupt	false	true	true
I2C4 error interrupt	false	true	true

\* User modified value

## 4. System Views

### 4.1. Category view

#### 4.1.1. Current

**Category view**

Power Domain view

Choose filters ... ... by Power Domain

D1
  D2
  D3
  None

#### Middleware

LWIP

System Core	Analog	Timers	Connectivity	Multimedia	Security	Computing	Trace and Debug	Power and Thermal
BDMA		TIM1	ETH				DEBUG	
CORTEX_M7		TIM8	FDCAN1					
DMA			FDCAN2					
GPIO			I2C4					
MDMA			UART4					
NVIC			UART5					
RCC			UART7					
SYS			USART1					
			USART2					
			USART3					
			USART6					

4.1.2. Without filters

Category view

Power Domain view



Choose filters ...

... by Power Domain

D1  D2  D3  None

Middleware

LWIP ✓

System Core

Analog

Timers

Connectivity

Multimedia

Security

Computing

Trace and Debug Power and Thermal

BDMA

TIM1 ✓

ETH ✓

DEBUG ✓

CORTEX\_M7 ✓

TIM8 ✓

FDCAN1 ✓

FDCAN2 ✓

DMA ✓

I2C4 ✓

GPIO ✓

UART4 ✓

MDMA

UART5 ✓

NVIC ✓

UART7 ✓

RCC ✓

USART1 ✓

SYS ✓


USART2 ✓

USART3 ✓

USART6 ✓

## 4.2. Power Domain view

Category view Power Domain view



## 5. Docs & Resources

Type	Link
BSDL files	<a href="https://www.st.com/resource/en/bsdl_model/stm32h7_bsd.zip">https://www.st.com/resource/en/bsdl_model/stm32h7_bsd.zip</a>
IBIS models	<a href="https://www.st.com/resource/en/ibis_model/stm32h7_ibis.zip">https://www.st.com/resource/en/ibis_model/stm32h7_ibis.zip</a>
System View Description	<a href="https://www.st.com/resource/en/svd/stm32h7-svd.zip">https://www.st.com/resource/en/svd/stm32h7-svd.zip</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/microcontrollers_stm32h7_series_product_overview.pdf">https://www.st.com/resource/en/product_presentation/microcontrollers_stm32h7_series_product_overview.pdf</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/stm32-stm8_embedded_software_solutions.pdf">https://www.st.com/resource/en/product_presentation/stm32-stm8_embedded_software_solutions.pdf</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/stm32_eval_tools_portfolio.pdf">https://www.st.com/resource/en/product_presentation/stm32_eval_tools_portfolio.pdf</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/stm32_stm8_functional-safety-packages.pdf">https://www.st.com/resource/en/product_presentation/stm32_stm8_functional-safety-packages.pdf</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/stm32-stm8_software_development_tools.pdf">https://www.st.com/resource/en/product_presentation/stm32-stm8_software_development_tools.pdf</a>
Presentations	<a href="https://www.st.com/resource/en/product_presentation/microcontrollers-stm32-family-overview.pdf">https://www.st.com/resource/en/product_presentation/microcontrollers-stm32-family-overview.pdf</a>
Brochures	<a href="https://www.st.com/resource/en/brochure/brstm32h7.pdf">https://www.st.com/resource/en/brochure/brstm32h7.pdf</a>
Brochures	<a href="https://www.st.com/resource/en/brochure/brstm32h7vl.pdf">https://www.st.com/resource/en/brochure/brstm32h7vl.pdf</a>
Brochures	<a href="https://www.st.com/resource/en/brochure/products-and-solutions-for-plcs-and-smart-i-os.pdf">https://www.st.com/resource/en/brochure/products-and-solutions-for-plcs-and-smart-i-os.pdf</a>
Flyers	<a href="https://www.st.com/resource/en/flyer/flstm32nucleo.pdf">https://www.st.com/resource/en/flyer/flstm32nucleo.pdf</a>
Flyers	<a href="https://www.st.com/resource/en/flyer/flstm32trust.pdf">https://www.st.com/resource/en/flyer/flstm32trust.pdf</a>
Flyers	<a href="https://www.st.com/resource/en/flyer/flpowerstbd.pdf">https://www.st.com/resource/en/flyer/flpowerstbd.pdf</a>
Application Notes	<a href="https://www.st.com/resource/en/application_note/an1181-electrostatic-discharge-sensitivity-measurement-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an1181-electrostatic-discharge-sensitivity-measurement-stmicroelectronics.pdf</a>
Application Notes	<a href="https://www.st.com/resource/en/application_note/an1709-emc-design-guide-for-stm8-stm32-and-legacy-mcus-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an1709-emc-design-guide-for-stm8-stm32-and-legacy-mcus-stmicroelectronics.pdf</a>
Application Notes	<a href="https://www.st.com/resource/en/application_note/an2606-stm32-microcontroller-system-memory-boot-mode-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an2606-stm32-microcontroller-system-memory-boot-mode-stmicroelectronics.pdf</a>

- Application Notes [https://www.st.com/resource/en/application\\_note/an2639-soldering-recommendations-and-package-information-for-leadfree-ecopack-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an2639-soldering-recommendations-and-package-information-for-leadfree-ecopack-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an2867-oscillator-design-guide-for-stm8afals-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an2867-oscillator-design-guide-for-stm8afals-stm32-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an3126-audio-and-waveform-generation-using-the-dac-in-stm32-products-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an3126-audio-and-waveform-generation-using-the-dac-in-stm32-products-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an3155-usart-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an3155-usart-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an3156-usb-dfu-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an3156-usb-dfu-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4013-stm32-crossseries-timer-overview-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4013-stm32-crossseries-timer-overview-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4221-i2c-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4221-i2c-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4229-how-to-implement-a-vocoder-solution-using-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4229-how-to-implement-a-vocoder-solution-using-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4277-using-stm32-device-pwm-shutdown-features-for-motor-control-and-digital-power-conversion-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4277-using-stm32-device-pwm-shutdown-features-for-motor-control-and-digital-power-conversion-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4286-spi-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4286-spi-protocol-used-in-the-stm32-bootloader-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4539-hrtim-cookbook-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4539-hrtim-cookbook-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4566-extending-the-dac-performance-of-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4566-extending-the-dac-performance-of-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4635-minimization-of-power-consumption-using-lpuart-for-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4635-minimization-of-power-consumption-using-lpuart-for-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4655-virtually-increasing-the-number-of-serial-communication-peripherals-in-stm32-](https://www.st.com/resource/en/application_note/an4655-virtually-increasing-the-number-of-serial-communication-peripherals-in-stm32-)

applications-stmicroelectronics.pdf

- Application Notes [https://www.st.com/resource/en/application\\_note/an4750-handling-of-soft-errors-in-stm32-applications-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4750-handling-of-soft-errors-in-stm32-applications-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4759-using-the-hardware-realtime-clock-rtc-and-the-tamper-management-unit-tamp-with-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4759-using-the-hardware-realtime-clock-rtc-and-the-tamper-management-unit-tamp-with-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4776-generalpurpose-timer-cookbook-for-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4776-generalpurpose-timer-cookbook-for-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4803-highspeed-si-simulations-using-ibis-and-boardlevel-simulations-using-hyperlynx-si-on-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4803-highspeed-si-simulations-using-ibis-and-boardlevel-simulations-using-hyperlynx-si-on-stm32-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4839-level-1-cache-on-stm32f7-series-and-stm32h7-series-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4839-level-1-cache-on-stm32f7-series-and-stm32h7-series-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4861-lcdtft-display-controller-ltcd-on-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4861-lcdtft-display-controller-ltcd-on-stm32-mcus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4891-stm32h72x-stm32h73x-and-singlecore-stm32h74x75x-system-architecture-and-performance-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4891-stm32h72x-stm32h73x-and-singlecore-stm32h74x75x-system-architecture-and-performance-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4908-stm32-usart-automatic-baud-rate-detection-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4908-stm32-usart-automatic-baud-rate-detection-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4936-migration-of-microcontroller-applications-from-stm32f7-series-to-stm32h743753-line-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4936-migration-of-microcontroller-applications-from-stm32f7-series-to-stm32h743753-line-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4989-stm32-microcontroller-debug-toolbox-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4989-stm32-microcontroller-debug-toolbox-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4990-getting-started-with-sigmadelat-digital-interface-on-applicable-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4990-getting-started-with-sigmadelat-digital-interface-on-applicable-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4996-hardware-jpeg-codec-peripheral-in-stm32f7677xxx-and-stm32h743534555475750a3b3b0xx-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4996-hardware-jpeg-codec-peripheral-in-stm32f7677xxx-and-stm32h743534555475750a3b3b0xx-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5020-digital-camera-](https://www.st.com/resource/en/application_note/an5020-digital-camera-)



interface-dcmi-on-stm32-mcus-stmicroelectronics.pdf

- Application Notes [https://www.st.com/resource/en/application\\_note/an5027-interfacing-pdm-digital-microphones-using-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5027-interfacing-pdm-digital-microphones-using-stm32-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5033-stm32cube-mcu-package-examples-for-stm32h7-series-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5033-stm32cube-mcu-package-examples-for-stm32h7-series-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5073-receiving-spdif-audio-stream-with-the-stm32f4f7h7-series-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5073-receiving-spdif-audio-stream-with-the-stm32f4f7h7-series-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5200-getting-started-with-stm32h7-series-sdmmc-host-controller-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5200-getting-started-with-stm32h7-series-sdmmc-host-controller-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5224-stm32-dmamux-the-dma-request-router-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5224-stm32-dmamux-the-dma-request-router-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5312-migration-from-revy-to-revv-for-stm32h743753-and-stm32h750-value-line-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5312-migration-from-revy-to-revv-for-stm32h743753-and-stm32h750-value-line-microcontrollers-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5337-stm32h7-series-lifetime-estimates-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5337-stm32h7-series-lifetime-estimates-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5354-getting-started-with-the-stm32h7-series-mcu-16bit-adc-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5354-getting-started-with-the-stm32h7-series-mcu-16bit-adc-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5543-enhanced-methods-to-handle-spi-communication-on-stm32-devices-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5543-enhanced-methods-to-handle-spi-communication-on-stm32-devices-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4760-quadspi-interface-on-stm32-microcontrollers-and-microprocessors-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4760-quadspi-interface-on-stm32-microcontrollers-and-microprocessors-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an4899-stm32-microcontroller-gpio-hardware-settings-and-lowpower-consumption-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4899-stm32-microcontroller-gpio-hardware-settings-and-lowpower-consumption-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5507-cyclic-redundancy-check-in-stm32h7-series-flash-memory-interface-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5507-cyclic-redundancy-check-in-stm32h7-series-flash-memory-interface-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5612-esd-protection-of-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5612-esd-protection-of-stm32-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5293-migration-guide-](https://www.st.com/resource/en/application_note/an5293-migration-guide-)

from-stm32f7-series-to-stmh74x75x-stm32h72x73x-and-stmh7a37bx-devices-stmicroelectronics.pdf

Application Notes [https://www.st.com/resource/en/application\\_note/an5156-introduction-to-stm32-microcontrollers-security-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5156-introduction-to-stm32-microcontrollers-security-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an4838-introduction-to-memory-protection-unit-management-on-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4838-introduction-to-memory-protection-unit-management-on-stm32-mcus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5348-introduction-to-fdcan-peripherals-for-stm32-product-classes-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5348-introduction-to-fdcan-peripherals-for-stm32-product-classes-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an4230-random-number-generation-validation-using-nist-statistical-test-suite-for-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4230-random-number-generation-validation-using-nist-statistical-test-suite-for-stm32-microcontrollers-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an4879-introduction-to-usb-hardware-and-pcb-guidelines-using-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4879-introduction-to-usb-hardware-and-pcb-guidelines-using-stm32-mcus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5225-introduction-to-usb-typec-power-delivery-for-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5225-introduction-to-usb-typec-power-delivery-for-stm32-mcus-and-mpus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5342--how-to-use-error-correction-code-ecc-management-for-internal-memories-protection-on-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5342--how-to-use-error-correction-code-ecc-management-for-internal-memories-protection-on-stm32-mcus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an2834-how-to-optimize-the-adc-accuracy-in-the-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an2834-how-to-optimize-the-adc-accuracy-in-the-stm32-mcus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an4938-getting-started-with-stm32h74xig-and-stm32h75xig-mcu-hardware-development-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4938-getting-started-with-stm32h74xig-and-stm32h75xig-mcu-hardware-development-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5816-how-to-build-stm32-lpbam-application-using-stm32cubemx-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5816-how-to-build-stm32-lpbam-application-using-stm32cubemx-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5537-how-to-use-adc-oversampling-techniques-to-improve-signaltonoise-ratio-on-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5537-how-to-use-adc-oversampling-techniques-to-improve-signaltonoise-ratio-on-stm32-mcus-stmicroelectronics.pdf)

Application Notes [https://www.st.com/resource/en/application\\_note/an5036-guidelines-for-thermal-management-on-stm32-applications-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5036-guidelines-for-thermal-management-on-stm32-applications-stmicroelectronics.pdf)

- Application Notes [https://www.st.com/resource/en/application\\_note/an5405-how-to-use-fdcan-bootloader-protocol-on-stm32-mcus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5405-how-to-use-fdcan-bootloader-protocol-on-stm32-mcus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an5690-how-to-use-vrefbuf-peripheral-on-stm32-mcus-and-mpus-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5690-how-to-use-vrefbuf-peripheral-on-stm32-mcus-and-mpus-stmicroelectronics.pdf)
- Application Notes [https://www.st.com/resource/en/application\\_note/an1202\\_freertos\\_guide-for\\_related\\_Tools\\_freertos-guide-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an1202_freertos_guide-for_related_Tools_freertos-guide-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an1602\\_semihosting\\_in\\_for\\_related\\_Tools\\_truestudio-how-to-do-semihosting-in-truestudio-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an1602_semihosting_in_for_related_Tools_truestudio-how-to-do-semihosting-in-truestudio-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an1801\\_stm32cubeprog\\_for\\_related\\_Tools\\_rammer\\_in\\_truestudio-installing-stm32cubeprogrammer-in-truestudio-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an1801_stm32cubeprog_for_related_Tools_rammer_in_truestudio-installing-stm32cubeprogrammer-in-truestudio-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/atollic\\_editing\\_keyboard\\_for\\_related\\_Tools\\_shortcuts-atollic-editing-keyboard-shortcuts-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/atollic_editing_keyboard_for_related_Tools_shortcuts-atollic-editing-keyboard-shortcuts-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/iar\\_to\\_atollic\\_truestudio\\_for\\_related\\_Tools\\_migration\\_guide-truestudio-for-arm-migration-guide-iar-embedded-workbench-to-truestudio-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/iar_to_atollic_truestudio_for_related_Tools_migration_guide-truestudio-for-arm-migration-guide-iar-embedded-workbench-to-truestudio-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/stm32cubemx\\_installatio\\_for\\_related\\_Tools\\_n\\_in\\_truestudio-stm32cubemx-installation-in-truestudio-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/stm32cubemx_installatio_for_related_Tools_n_in_truestudio-stm32cubemx-installation-in-truestudio-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an4323-getting-started-for\\_related\\_Tools\\_with-stemwin-library-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4323-getting-started-for_related_Tools_with-stemwin-library-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an4435-guidelines-for-obtaining-ulcsaiec-607301603351-class-b-certification-in-any-stm32-application-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4435-guidelines-for-obtaining-ulcsaiec-607301603351-class-b-certification-in-any-stm32-application-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an4635-minimization-of-power-consumption-using-lpuart-for-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4635-minimization-of-power-consumption-using-lpuart-for-stm32-microcontrollers-stmicroelectronics.pdf)  
& Software
- Application Notes [https://www.st.com/resource/en/application\\_note/an4657-stm32-inapplication-programming-iap-using-the-usart-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4657-stm32-inapplication-programming-iap-using-the-usart-stmicroelectronics.pdf)  
& Software

- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an4759-using-the-hardware-realtime-clock-rtc-and-the-tamper-management-unit-tamp-with-stm32-microcontrollers-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4759-using-the-hardware-realtime-clock-rtc-and-the-tamper-management-unit-tamp-with-stm32-microcontrollers-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an4841-digital-signal-processing-for-stm32-microcontrollers-using-cmsis-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4841-digital-signal-processing-for-stm32-microcontrollers-using-cmsis-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an4891-stm32h72x-stm32h73x-and-singlecore-stm32h74x75x-system-architecture-and-performance-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an4891-stm32h72x-stm32h73x-and-singlecore-stm32h74x75x-system-architecture-and-performance-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5001-stm32cube-expansion-package-for-stm32h7-series-mdma-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5001-stm32cube-expansion-package-for-stm32h7-series-mdma-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5014-stm32h7x3-smart-power-management-expansion-package-for-stm32cube-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5014-stm32h7x3-smart-power-management-expansion-package-for-stm32cube-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5033-stm32cube-mcu-package-examples-for-stm32h7-series-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5033-stm32cube-mcu-package-examples-for-stm32h7-series-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5054-secure-programming-using-stm32cubeprogrammer-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5054-secure-programming-using-stm32cubeprogrammer-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5056-integration-guide-for-the-xcubesbsfu-stm32cube-expansion-package-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5056-integration-guide-for-the-xcubesbsfu-stm32cube-expansion-package-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5360-getting-started-with-projects-based-on-the-stm32mp1-series-in-stm32cubeide-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5360-getting-started-with-projects-based-on-the-stm32mp1-series-in-stm32cubeide-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5361-getting-started-with-projects-based-on-dualcore-stm32h7-microcontrollers-in-stm32cubeide-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5361-getting-started-with-projects-based-on-dualcore-stm32h7-microcontrollers-in-stm32cubeide-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5394-getting-started-with-projects-based-on-the-stm32l5-series-in-stm32cubeide-stmicroelectronics.pdf](https://www.st.com/resource/en/application_note/an5394-getting-started-with-projects-based-on-the-stm32l5-series-in-stm32cubeide-stmicroelectronics.pdf)
- Application Notes for related Tools & Software [https://www.st.com/resource/en/application\\_note/an5418-how-to-build-a-](https://www.st.com/resource/en/application_note/an5418-how-to-build-a-)

for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5426-migrating-graphics-middleware-projects-from-stm32cubeide-stm32cubeide-stmicroelectronics.pdf">simple-usbpd-sink-application-with-stm32cubeide-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5564-getting-started-with-projects-based-on-dualcore-stm32wl-microcontrollers-in-stm32cubeide-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5426-migrating-graphics-middleware-projects-from-stm32cubeide-stm32cubeide-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an4865-lowpower-timer-lptim-applicative-use-cases-on-stm32-mcus-and-mpus-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5564-getting-started-with-projects-based-on-dualcore-stm32wl-microcontrollers-in-stm32cubeide-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5698-adapting-the-xcubestl-functional-safety-package-for-stm32-iec-61508-compliant-to-other-safety-standards-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an4865-lowpower-timer-lptim-applicative-use-cases-on-stm32-mcus-and-mpus-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5731-stm32cubeide-threadsafe-solution-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5698-adapting-the-xcubestl-functional-safety-package-for-stm32-iec-61508-compliant-to-other-safety-standards-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5450-stm32h7a37b3-lines-and-stm32h7b0-value-line-smart-power-management-expansion-package-for-stm32cube-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5731-stm32cubeide-threadsafe-solution-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an4502-stm32-smbuspmbus-expansion-package-for-stm32cube-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5450-stm32h7a37b3-lines-and-stm32h7b0-value-line-smart-power-management-expansion-package-for-stm32cube-stmicroelectronics.pdf</a>
Application Notes for related Tools & Software	<a href="https://www.st.com/resource/en/application_note/an5952-how-to-use-cmake-in-stm32cubeide-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an4502-stm32-smbuspmbus-expansion-package-for-stm32cube-stmicroelectronics.pdf</a>
Design Notes & Tips	<a href="https://www.st.com/resource/en/design_tip/dt0117-microphone-array-beamforming-in-the-pcm-and-pdm-domain-stmicroelectronics.pdf">https://www.st.com/resource/en/application_note/an5952-how-to-use-cmake-in-stm32cubeide-stmicroelectronics.pdf</a>
Errata Sheets	<a href="https://www.st.com/resource/en/errata_sheet/es0392-stm32h742xig-stm32h743xig-stm32h750xb-stm32h753xi-device-errata-stmicroelectronics.pdf">https://www.st.com/resource/en/design_tip/dt0117-microphone-array-beamforming-in-the-pcm-and-pdm-domain-stmicroelectronics.pdf</a>
Datasheet	<a href="https://www.st.com/resource/en/datasheet/dm00387108.pdf">https://www.st.com/resource/en/errata_sheet/es0392-stm32h742xig-stm32h743xig-stm32h750xb-stm32h753xi-device-errata-stmicroelectronics.pdf</a>
Programming Manuals	<a href="https://www.st.com/resource/en/programming_manual/pm0253-stm32f7-series-and-stm32h7-series-cortexm7-processor-programming-manual-">https://www.st.com/resource/en/datasheet/dm00387108.pdf</a>

	<a href="#">stmicroelectronics.pdf</a>
Reference Manuals	<a href="https://www.st.com/resource/en/reference_manual/rm0433-stm32h742-stm32h743753-and-stm32h750-value-line-advanced-armbased-32bit-mcus-stmicroelectronics.pdf">https://www.st.com/resource/en/reference_manual/rm0433-stm32h742-stm32h743753-and-stm32h750-value-line-advanced-armbased-32bit-mcus-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1163-description-of-wlcsp-for-microcontrollers-and-recommendations-for-its-use-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1163-description-of-wlcsp-for-microcontrollers-and-recommendations-for-its-use-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1204-tape-and-reel-shipping-media-for-stm32-microcontrollers-in-bga-packages-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1204-tape-and-reel-shipping-media-for-stm32-microcontrollers-in-bga-packages-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1205-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-fpn-packages-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1205-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-fpn-packages-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1206-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-qfp-packages-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1206-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-qfp-packages-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1207-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-so-packages-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1207-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-so-packages-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1208-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-tssop-and-ssop-packages-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1208-tape-and-reel-shipping-media-for-stm8-and-stm32-microcontrollers-in-tssop-and-ssop-packages-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1433-reference-device-marking-schematics-for-stm32-microcontrollers-and-microprocessors-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1433-reference-device-marking-schematics-for-stm32-microcontrollers-and-microprocessors-stmicroelectronics.pdf</a>
Technical Notes & Articles	<a href="https://www.st.com/resource/en/technical_note/tn1489-security-bulletin-tn1489stpsirt-physical-attacks-on-stm32-and-stm32cube-firmware-stmicroelectronics.pdf">https://www.st.com/resource/en/technical_note/tn1489-security-bulletin-tn1489stpsirt-physical-attacks-on-stm32-and-stm32cube-firmware-stmicroelectronics.pdf</a>
User Manuals	<a href="https://www.st.com/resource/en/user_manual/um2840-stm32h7-dualcore-series-safety-manual-stmicroelectronics.pdf">https://www.st.com/resource/en/user_manual/um2840-stm32h7-dualcore-series-safety-manual-stmicroelectronics.pdf</a>
User Manuals	<a href="https://www.st.com/resource/en/user_manual/um2331-stm32h7-singlecore-series-safety-manual-stmicroelectronics.pdf">https://www.st.com/resource/en/user_manual/um2331-stm32h7-singlecore-series-safety-manual-stmicroelectronics.pdf</a>